

Nautilarm Text Commands

General Use:	Command:	V2	V3	V3G
Arm/Disarm Nautilarm	secret, arm/disarm	✓	✓	✓
Turn GPS on or off	secret, gps, on/off		✓	✓
Turn switched circuit on or off	secret, switch, on/off	✓	✓	✓
Turn named circuit on or off	secret, name/lights, on/off	✓	✓	✓
Get Nautilarm status	secret, status	✓	✓	✓
Check credit	secret, credit	✓	✓	✓
Setup:				
Set master mobile no.	secret, master, set	✓	✓	✓
Delete master mobile no.	secret, master, delete	✓	✓	✓
Request master mobile no.	secret, master	✓	✓	✓
Set 2nd mobile number	secret, phone, 1, phone_number	✓	✓	✓
Set 3rd mobile number	secret, phone, 2, phone_number	✓	✓	✓
Delete 2nd mobile no.	secret, phone, 1, delete	✓	✓	✓
Delete 3rd mobile no.	secret, phone, 2, delete	✓	✓	✓
Change password	secret, password, newpassword	✓	✓	✓
Set auto status time (mins)	secret, auto, 20160	✓	✓	✓
Disable auto reporting	secret, auto, disable	✓	✓	✓
Set low voltage alarm	secret, voltage, limit	✓	✓	✓
Disable low voltage alarm	secret, voltage, disable	✓	✓	✓
Set entry, exit & alarm times (secs)	secret, time, entry, exit, alarm	✓	✓	✓
Name alarm channel	secret, name, 1, newname	✓	✓	✓
Name switch channel	secret, name, 8, switched_circuit	✓	✓	✓
Set keyswitch	secret, key, disable/enable	✓	✓	✓
Set tamper zone	secret, tamper, disable/enable	✓	✓	✓
Set credit check string	secret, credit, *#1345#	✓	✓	✓
Beam break test mode - chan 4-7)	secret, beam, test, channel		✓	✓
Disable beam test mode	secret, beam, test, disable		✓	✓
Describing which circuits are Beam	secret, beam, ch4, ch5, ch6, ch7		✓	✓
Disables geofencing	secret, fence, disable			✓
Queries geofence settings	secret, fence			✓
set fence radius (*10m) full alarm	secret, fence, radius, alarm			✓
set fence radius (*10m) message	secret, fence, radius, message			✓
Set credit check string	secret, credit, *#1345#	✓	✓	✓
Reset to factory parameters	secret, reset	✓	✓	✓